



APM RapidMask Instructions

- 1. The film is extremely light sensitive and should be used out of direct sunlight.**
2. Desk top printing technology now makes it possible to quickly reproduce a customer's logo or design and add text or additional graphics. Ideally the artwork **should be printed onto AccuArt inkjet film**, AccuArt gives precise exposure drafts and reduces the loss of the film's self adhesive power. If you do not have facilities to print using an inkjet printer a laser printer can be used to print onto tracing vellum or Folex film although the quality will not be to the same level as artwork printed onto AccuArt.
3. Lay the emulsion side of the RapidMask film towards the UV light source and place the toner side of the laser film on top of that. The emulsion side of the film has a duller appearance compared to the shiny carrier sheet.
4. The film is UV exposed for approximately 50 seconds on a Pluvex flat bed exposure unit or 40 seconds on a Pressure Pad exposure unit, in order to achieve the correct exposure time for alternative exposure units we would recommend a step wedge test.
5. When the film has been exposed remove it from the exposure unit. Prior to applying the film to the glass the slip sheet should be removed. The easiest way to do this is to apply a piece of masking tape to each side of one corner of the sheet, then pull the two pieces of tape and the slip sheet will come away.
6. To transfer the stencil onto the glass simply rub down the stencil with a plastic burnisher and peel off the clear carrier sheet. Now you are ready to sandblast the glass.
7. We recommend 30-40psi blasting pressure for most items, holding the nozzle 4-6 inches away, blast until all of the dark areas of your design become clear.
8. After the design has been completely sandblasted the quickest method to remove the resist is to place the glass in warm water for several minutes and then peel the stencil from the glass gently rubbing with your fingers.
9. Once the stencil has been removed dry the glass using a towel or tissue.

If you require any assistance please do not hesitate to contact us.

Edward House, 2 Westerby Road, Middlesbrough, Cleveland TS3 8TD

Telephone 01642 225799 Fax 01642 217928

sales@crystalgalleries.co.uk www.crystalgalleries.co.uk